



PIVOT DOOR PENTAGON & OFFSET PENTAGON

SUPREME



PIVOT DOOR OFFSET PENTAGON

INSTALLATION INSTRUCTIONS



IMPORTANT - Please read before installation

Please read these instructions carefully before starting installation and keep in a safe place for future reference.

Check the contents of the pack carefully before installation. Simpsons will not be held responsible for any de-fit / re-fit costs where faulty product has been fitted.


If any fault is found with materials or workmanship, it must be reported immediately to the manufacturer. Remedial action will be taken, based on information received, on condition that: 1. Full details are supplied to the manufacturer; 2. The enclosure has not been modified or tampered with; 3. The manufacturer is informed of any damage/shortages prior to installation.

We do not accept responsibility for any problems that may occur through incorrect installation.

The success of the installation and operation of any shower enclosure is, of course, dependant on the squareness, alignment and construction of the walls to which fixing is to be carried out.

VERY IMPORTANT

You must complete all tiling and grouting, and the shower tray **MUST** be level and fully sealed to the tiles before installation. If you do not fit the enclosure onto a tiled surface, or seal the tiles to the tray before installation, water may soak into the wall behind the wall channels.



INSTALLATION - Advice and safety

All Supreme shower doors and panels are fully assembled and are reversible for left or right hand fitting, simply turn the door or panel up side down.

The Supreme doors come with the two wall channels pushed onto each side of the door frame. The side panels and inline panels do **NOT** come with wall channels, you must use one of the channels from the door.

The installation instructions are based on typical use and conditions.

The pivot doors are designed to open outwards only.

Please follow the installation instructions relevant to your enclosure.

These hints have been prepared for your guidance, you must exercise due care at all times.

It is recommended that 2 people carry out the installation of this enclosure.

Handle glass with care. Although the glass supplied is toughened

safety glass (to EN12150), impacts can damage both the glass and the frame.

Warning! Please check for any hidden pipes or cables before drilling holes in the wall.

To stop the drill bit slipping, masking tape can be applied to the tiles when preparing the holes.

When using power tools always follow the manufacturers user instructions.

Do not sit the enclosure on a bed of silicone, as this will also stop any water from draining back into the tray.

DO NOT SEAL THE ENCLOSURE TO THE TRAY ON THE INSIDE

If the enclosure is sealed to the tray on the inside, any water that may get into the framework will not be able to drain back into the tray, this may cause the enclosure to leak.















Leave the silicone sealant to dry for 24 hours before using the enclosure.

CARE AND CLEANING

Do not use solvents or abrasive materials or chemicals to clean the enclosure.

Only clean using soapy water and a soft cloth, rinse thoroughly afterwards.

CONTENTS




Tools and equipment needed

Drill, 6mm Masonry drill bit, 3.5mm General drill bit, Phillips screwdriver, Spirit level, Pencil, Scissors, Silicone sealant.

PIVOT DOOR PENTAGON




Step 1



Remove both wall channels from the door frame. Place each wall channel in position on the tray (10 - 15mm in from the outer edges of the tray), use a spirit level to ensure they are vertical and mark all 8 fixing holes onto the walls (holes inside).

Drill holes in the positions marked using a 6mm masonry drill bit. Insert wall plugs (C) into all of the holes (beyond the thickness of the tile). Fix the wall channels to the wall using 8 x 38mm screws (B) and push on the screw covers (D).

Note: Inject silicone sealant into the holes before inserting the screws to seal the holes.




Step 2

Insert the pent panels into the wall channels and position correctly on the tray.


Note: The drain slot running across the top and bottom of the pent panels MUST be on the inside of the enclosure.

Warning: Take care, the pent posts are not fixed to the pent panels.



Step 3


Insert the door into the pent posts positioned on the pent panels.



Step 4

Before fixing the door and pent panels to the wall channels and pent posts you must make sure that the door is square within its outer frame.

First, centre the door between the pent posts. Next, with the door closed the 4mm gap between the bottom of the door and the frame MUST be parallel all the way across. If the gap is not parallel, push the top of the door frame to the left or right so the door hangs squarely within its outer frame.



Step 5


Once you have checked that the door opens and closes correctly and the pent posts are vertical, fix the pent panels to the wall channels and pent posts and fix the door to the pent posts.

From inside, drill 3 holes through each wall channel into the pent panels (in the marked positions) using a 3.5mm drill bit.

Note: Stop drilling as soon as you feel the drill break through the first 2 layers of aluminium. Fix using 6 x 10mm screws (A) and push on the screw covers (D).

Check again that the pent posts are vertical, and drill 6 more holes through each pent post into the door and pent panels (in the marked positions) using a 3.5mm drill bit.

Note: Stop drilling as soon as you feel the drill break through the first 2 layers of aluminium. Fix using 6 x 10mm screws (A) and push on the screw covers (D).



Step 6

When installing the offset enclosure, the brace bar should be fixed to the NARROW pent panel.

Fit the brace bar (F). Position the brace bar in the corner with one end on the pent panel and the other against the wall. Use a spirit level to ensure it is level and mark the screw hole positions onto the pent panel and wall.


Drill a hole in the position marked on the wall using a 6mm masonry drill bit. Insert a wall plug (C) into the hole (beyond the thickness of the tile). Drill a 3.5mm hole in the position marked on the pent panel.

Note: Stop drilling as soon as you feel the drill break through the first layer


of aluminium. Fix the brace bar to the wall using a 38mm counter sunk screw (H).

Note: Inject silicone sealant into the hole before inserting the screw to seal the hole.

Fix to the pent panel using a 15mm counter sunk screw (G).




Step 7




Sealing inside: Run a line of silicone sealant from top to bottom down the joint between the wall channels and tiles. Run a line of silicone sealant from top to bottom down the joint where the pent panels slot into the wall channels and the pent panels and door slot into the pent posts.

Do not seal the enclosure to the tray on the inside.




Sealing outside: Run a line of silicone sealant from top to bottom down the joint between the wall channels and tiles. Run a line of silicone sealant 100mm up the joint where the pent panels slot into the wall channels and pent posts. Run a line of sealant around the base in the joint between the bottom of the enclosure and the tray, from wall to wall.

Step 8



Optional: It is only necessary to fit the plastic Anti splash strip (E) if water splashes out through the gap under the door. Cut the strip to size (using scissors) and push fit onto the lug shown on the bottom door frame as shown.

Note: If the anti splash strip catches on the door, simply trim to fit.



SIMPSONS

For any further information please contact
Simpsons on: **01483 303711**

Or visit our web-site at:
www.simpsons-enclosures.co.uk

The manufacturer reserves the right to make technical
modifications without prior notice.